## 2. Preparatory work

The following components must be removed first of all	ISTA No.
Only for the 330i: Remove the exhaust flap control	

© BMW AG, Munich. 01 29 2 240 838 (V/Z)