Bavarian Otto's Ultimate Maintenance Schedule

The savvy enthusiast's guide to proper maintenance intervals for improving performance and prolonging the life of your BMW or MINI.



3 Series sedan 06 on (E90 Chassis)	1 year	2 years	3 years	4 years	5 years	6 years	Engine Oil	
Annual Inspection (1yr/15K) – See below							Petroleum-based (Change every 3,750mi.)	Synthetic (Change every 7,500mi.)
Brake Fluid (1yr/15K)							Oil Weight: (Example: 5W-30)	Brand:
Cabin Microfilter (1yr/15K)							Record date/mile	age in boxes below:
Engine Air Filter (1yr/15K)								
Transfer Case Fluid (2yr/50K) – XI, Xdrive only								
Manual Transmission Fluid (2yr/50K)								
Automatic Transmission Fluid & Filter (2yr/50K)								
Differential Fluid (2yr/50K)								
Power Steering Fluid (2yr/50K)								
Fuel Filter (3yr/45K)								
Flush Coolant (3yr/45K)								
Accessory Drive Belts (4yr/60K)								
Spark Plugs (4yr/60K)								
Coolant Hoses (4yr/60K)								
Water Pump (6yr/100K)								
Oxygen Sensor (6yr/100K)								
Charcoal Canister (6yr/100K)								

Annual Inspection. Once a year, or every 15,000 miles, you should inspect drive belts, water pump and fan clutch, coolant hoses, suspension and steering linkages and joints, driveshaft flex discs, engine and transmission mounts, brake pads/rotors/calipers/hoses, exhaust systems, fluids, etc., looking for premature wear. We describe everything you need to do in the Winter, Spring and Summer 2009 issues of our tech newsletter, *Fast Times*. You can read/download the issues at www.BavAuto.com/newsletter. (Go to the Archives section and click on 2009.) And if you have any questions, call "Otto" at the number(s) listed at right during normal business hours (Mon thru Thu 8am–9pm; Fri 8am–7pm; Sat 9am–4pm).

